

FUNCTION WIRE STRIPE COLOR

Ground (GD)	=	White
Left Turn (LT)	=	Yellow
Right Turn (RT)	=	Green
Taillight/Marker (TM)	=	Brown

INSTRUCTIONS:

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Use the chart above to attach the wires of the Endurance™ 4-wire flat to the vehicle.
3. Plug into trailer and check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / marker lights and operate directional signals to check right / left turn.

NOTE:

Have trailer on ball of vehicle when testing trailer functions.

When the right turn signal is activated, the LED above "RT" on the 4-wire flat should activate. This should also be the case for the left turn ("LT"), taillight / marker ("TM") and brake ("RT" and "LT").

Grease applied to the terminals on a regular basis will help prevent corrosion.

FUNCIÓN DEL CABLE SEGÚN EL COLOR

Conexión a tierra (GD)	=	Blanco
Giro izquierdo (LT)	=	Amarillo
Giro derecho (RT)	=	Verde
Luz trasera/(TM) de posición	=	Marrón

INSTRUCCIONES:

1. Elija una ubicación de instalación en la parte trasera del vehículo o dentro del baúl. Evite el sistema de escape, los amortiguadores y el sistema de transmisión.
2. Utilice el esquema anterior para conectar los cables planos de 4 vías Endurance™ al vehículo.
3. Enchúfelo al remolque y verifique el sistema de iluminación para asegurar una operación correcta. Pise el freno para verificar las luces de freno, encienda los faros delanteros para verificar las luces traseras o de posición y haga funcionar las señales de dirección para verificar el giro derecho y el izquierdo.

NOTA:

Cuando se verifica el funcionamiento del remolque, debe estar sujetado a la bola de enganche del vehículo.

Cuando se activa la señal de giro derecho, debería activarse el LED que se encuentra sobre "RT" (giro derecho) del cable plano de 4 vías. Asimismo, debería activarse el giro izquierdo ("LT"), las luces traseras y de posición ("TM") y la luz de freno derecha e izquierda ("RT" y "LT").

La aplicación periódica de grasa a los terminales ayuda a evitar la corrosión.

Need Help? (English Only)

1 800 835-0129

techsupport@hopkinsmfg.com

www.hopkinstowingsolutions.com