



INSTALLATION INSTRUCTION PJ2000 / PJ2001 CRAWLER REAR BUMPERS

UNPACK YOUR BUMPER AND CHECK THE PACKAGE CONTENTS AGAINST THE FOLLOWING LIST. If you do not have all the parts listed below, call 661-398-9585.

Package contents:

- 1) PJ2000 or PJ2001 Rear Bumper
- 1) Hardware Kit Consisting of the Following:
 - 8) 1/2-13 x 1-1/2 Button Head Cap Screws
 - 8) 1/2 Flat Washers
 - 8) 1/2 Lock Washers
 - 8) 1/2-13 Standard Nuts
 - 2) 1/2-13 x 4-1/2 Grade 8 Bolts
 - 2) 1/2-13 x Lock Nuts
 - 4) 1/2 Grade 8 Flat Washers
 - 2) Crush Sleeves
- 1) Pair of Inner Frame L-brackets, (1 RH and 1 LH).
- 1) Installation Instruction sheet

Note: If you ordered a PJ2001 you should have also received a second box containing the swing-way tire carrier, swing-away hardware and installation instructions.

Disclaimer

PUREJEEP has made every effort to provide correct information. Each item has been fit checked for accuracy. PUREJEEP reserves the right to alter, make changes or replace part numbers and descriptions without notice. PUREJEEP will not be held responsible for changes or misprints or manufacturing changes made by the vehicle manufacturer. For questions regarding PUREJEEP components call our Technical Support Department at 661-304-0306

BEGIN THE INSTALLATION

STEP 1)

Unpack your bumper and place it on a soft, clean surface. An old blanket or large towel is ideal to help protect your bumper prior to installation. Ensure that you have the necessary tools to complete your installation and that all the hardware is accounted for.

STEP 2)

