

INSTALLATION INSTRUCTIONS

Part Number 30527 & 20507 Rear Bumper Bracket



Measure and mark the rear cross member holes centered at $31 \frac{7}{8}$ ".

Place the rear bumper brackets on the rear cross member, and fasten using the $\frac{3}{8}$ " stainless steel bolts provided. Place the front bumper 30436 or 30437 on the brackets and fasten using the stainless bolts provided. We recommend that you use anti-sieze on all threads of the stainless bolts provided with your parts.

INSTALLATION INSTRUCTIONS

Part Number 30527 & 20507 Rear Bumper Brackets



Measure and mark the rear cross member holes centered at $31 \frac{7}{8}$ ".

Place the rear bumper brackets on the rear cross member, and fasten using the $\frac{3}{8}$ " stainless steel bolts provided. Place the front bumper 30436 or 30437 on the brackets and fasten using the stainless bolts provided. We recommend that you use anti-sieze on all threads of the stainless bolts provided with your parts.