



11252.55

Step 4. Using the supplied hex driver attach the body bracket using the hex screws with a lock washer on each screw. Do not overtighten screws.

Step 5. Fold the carpet back in front of the body bracket. Using a knife or scissor make a small horizontal cut in the carpet. Slide the carpet over the body bracket and tuck the carpet back into its original position.

Step 6. Snap the enclosed black cylinder end of the strut onto the body bracket.

Step 7. With the tailgate open completely and the strut fully extended mark the two mounting holes for the tailgate bracket. The bracket should be centered between the rolled edge of the tailgate and the black plastic tailgate cover.











Step 9. Using the supplied hex driver attach the tailgate bracket using the hex screws with a lock washer on each screw. Do not over tighten.

Step 10. Snap the strut end onto the ball mount. Close the tailgate and open to ensure proper alignment and function.

Caution: This product is designed to assist with opening the tailgate only. Do not rely on this item to hold open the tailgate under all conditions.

> For Technical Assistance Contact: Omix-Ada Tech Support Phone: 1-800-449-6649 Email: techsupport@omix-ada.com Web: www.Omix-Ada.com

> > Copyright Omix-Ada 2011





