

# 11486

**07-13 JEEP  
WRANGLER**



# 11486

**07-13 JEEP  
WRANGLER**

## T1 SERIES ACCENTS FOG LIGHT RINGS

### Tools Required:

Screwdriver Set  
Marker  
Drill Bit Set/Drill

### Hardware / Parts List:

2 Fog Light Accents  
8 6/32 x 1/2" Polished Screws

### Step 1

Read and understand all instructions before attempting the install of this grille. Be sure that the package of hardware matches the hardware list as listed above. Next, test fit the T-REX accent to the vehicles factory openings. You are now ready for the install:



### Step 2

Making sure that the fog light accent is centered, mark each hole using a bright colored marker. After the holes are marked, drill pilot holes where you have previously marked (1). **DO NOT DRILL THE HOLES BIGGER THAN THE SCREWS!** Place the screws into the holes. Tighten each screw snug so not to strip out the plastic. Repeat this process on the opposite of the bumper.

***Thank you for purchasing your T-Rex billet grille. 8/7/08***