

INSTALLATION INSTRUCTIONS FOR

DYNOMAX SUPER TURBO AXLE-BACK KIT: 39528

2014-12 Jeep Wrangler, Wrangler Unlimited 3.6L

2011-07 Jeep Wrangler, Wrangler Unlimited 3.8L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN BUMPER JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS, IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT, IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. muffler assembly from behind the OE intermediate pipe. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax Super Turbo SS muffler assembly **53879**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the OE intermediate pipe. Insert both rod hangers.
3. Install DynoMax SS tips **36472**. See the system diagram on the back page of these instructions.
4. Beginning at the inlet end, align the muffler assembly and fully tighten all the clamps.

KIT CONTAINS:

- (1) 53879 Muffler
- (2) 36472 Tip w/Clamp
- (1) 36438 Band Clamp
- (1) Instruction Sheet

39528 SYSTEM DIAGRAM

