



JEEP CHEROKEE CB MOUNT INSTALLTION INSTRUCTIONS

TOOLS NEEDED

- 10mm Socket
- Socket Wrench
- Socket extension, Recommended

**Please read the mounting instructions below
carefully before attempting to install.**

Thank you for purchasing your new CB Mount from JcrOffroad!
Checkout our website, www.jcroffroad.com for more deals and
other great off-road products. Be sure to rate and review our prod-
uct online. If you have any questions or are missing parts, please
don't hesitate to call us at 269-353-1184!

Note: The photos here are of a '97-'01 but the install is the same on '84-'96 XJ's. The only difference is the bolts are in slightly different locations.

- 1** Using the 10mm Socket, remove the two top mounting bolts from your tail light housings.



- 2** Loosen the remaining bolts.

- 3** Pull the taillight housing away from the Jeep slightly.

- 4** Slide the XJ CB Mount as shown between the taillight housing and the body of the XJ until the holes line up with the bolt holes in the taillight housings.

- 5** Using the 10mm Socket again, screw back in the two bolts that you removed until tight, and tighten the lower bolt.



- 6** Follow the install instructions included with your CB Antenna for installing the antenna to our mount.