



INSTALLATION GUIDE

Installation Guide for the ZJ 1.5-inch Budget Boost kit Part #001381200 (BB1Z)

Kit Includes:

- 2 front bumpstop extensions (1.5" tall)
- 2 bolts (10mm x 55mm) for front bumpstops
- 2 rear bumpstop extensions (1.25" x 3" tall)
- 4 bolts (8mm x 60mm) for rear bumpstops
- 4 5/16 flat washers

Installation:

1. Jack up the vehicle by the frame and secure it with jack stands.
2. Remove the shocks.
3. Remove the rubber bump stops by grasping the bump stops and pulling down with a side to side motion.
4. Use a 15mm socket to remove the bolt inside both bump stop cups.
5. Remove the springs.
6. With 16mm socket and new bolt (10mm x 55mm 1.5 pitch) replace the bump stop cup placing the spacer between the bump stop cup and the bump stop pedestal. Install rear spacer.
7. Reinstall the springs, placing black spring spacers above the springs.
8. Reinstall shocks.



Attention:

Adverse handling characteristics and drive line angles may result when combining 1.25 or 1.5-inch spring spacers with aftermarket lifts. The use of any spring spacer in addition to TeraFlex suspension systems will void any warranty claims on TeraFlex springs.

Tera Manufacturing, Inc., 5251 South Commerce Dr., Murray, Utah 84107 Phone/801.288.2585 Fax/801.713.2313 www.teraflex.biz