

CLOVER PATCH WINDOW ROLL™ INSTRUCTIONS for the 2 door & 4 door JK models

Pat. Pending #60/420,912

1. Lay the felt on a clean flat surface with bound (sewn) edge facing you. Lay each quarter window in lengthwise, between full sheets of felt with stiff end at the bound edge (see photo). The windows must be clean prior to storage. If the tailgate bar is attached to the rear window, remove it and set aside. You can store the tailgate bar in the Window Roll. See below.
2. Place the rear window in last. Place the tailgate bar above the rear window if it is being stored in the Window Roll.



3. Roll the three windows up starting at the CLOSED end of the felt flaps. Wrap the straps around the window roll. This will hold the windows in the rolled position as shown. Do not roll the windows tightly as there is ample room in the nylon bag for the windows. You may find an edge of a window sticking out of the roll. This is normal and has no effect.
4. Insert the window roll into the outer bag and close the draw strings on each end. Lay the bag (Generally seam down is best – tag on driver's side) on top of the folded down top, or across the tub if the top is up, and buckle the bag to the roll bar. Do not pull the straps too tight, just snug.



The outer protective bag should fit snugly around the window roll felt as not to cause any flapping. During hot weather the windows may flatten some on top. This is considered normal and does not harm the windows. Check the buckles from time to time to insure the bag is secure.

Only pull the straps snug, not tight.

The nylon bag is coated to prevent dust and dirt from getting on the felt and windows. This bag is easily washable and dries quickly. The felt should never need cleaning but can be cleaned in a washing machine, hand wash and low heat.

If replacement parts are needed contact us as we stock all spare parts.

The window roll carries a 90 day limited warranty against all workmanship and material. The warranty does not cover damage or failure caused by improper installation, accident, or misuse. Do not place objects on top of the window roll. The Window Roll is water resistant; however never leave windows in the Window Roll when wet. Additional exclusions apply.

We at Clover Patch take great pride in customer satisfaction. Please contact us with questions or comments at:

Clover Patch Inc.
5706 Clover Dr.
Crestwood, KY 40014
Phone: 502-241-3026
Fax: 502-243-3267
E-mail: cloverpatch@insightbb.com