



Installation Instructions
for
Front Skid Plate, JP-5000 and JP-5009
for
2007-up Jeep® JK Wrangler

Thank you for purchasing your new Skid Row Offroad front skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

- | | |
|--|-------------------------------|
| 1. (1) Front Skid Plate | 5. (2) 3/8 Small Flat Washers |
| 2. (4) 3/8-16 x 1" Carriage Head Bolts | 6. (6) 3/8 Large Flat Washers |
| 3. (2) 3/8-16 x 1" Hex Head Bolts | 7. (6) 3/8 Lock Washers |
| 4. (6) 3/8-16 Hex Nuts | |

Step 1: Remove the factory plastic front "skid plate".

Step 2: Lift the front skid plate into place and simply bolt it to the frame as shown in the photo below. Use the two hex head bolts at the top and the four carriage head bolts at the bottom of the skid plate. Place the 2 small flat washers under the heads of the hex bolts to prevent damage to the finish. The 6 large flat washers are used under the nuts and lock washers.

Step 3: Tighten all six bolts and you're ready to hit the trail!

We hope you enjoy your new Skid Row Offroad Front skid plate!

Sincerely,

The Staff at SFK Manufacturing, LLC



SFK Manufacturing, LLC
PO Box 306, Shermans Dale, PA 17090
Phone 717-582-3640
Fax 717-582-2640

www.SkidRowOffroad.com



You could win a cool Skid Row Offroad jacket customized just for you by registering your new purchase at www.SkidRowOffroad.com/registration/

Annual Drawing to be held January 1st. Winner to be selected from all entries from prior year. All entries must be received by December 31st to be included in drawing. One entry per person per Skid Row Offroad product purchased.

