

# TERAFLEX

## INSTALLATION GUIDE

### **Installation Guide for the '99 and Newer Grand Cherokee Quick Disconnects Kit Part #001493000(QDFW)**



- 1.. Install the lower mounting stud. Place the metal sleeve where the sway bar originally connected. The lower mounting stud inserts where the bolt that secured the lower end of the sway bar link was located. The stud portion points to the outside of the vehicle. Use Loctite and secure with a nut.
2. Install the upper mounting stud into the hole in the end of the front sway bar. *Note: The upper mounting stud is shorter than the lower one. Use Loctite on the stud and fasten securely.*
3. The disconnect arm connects as one piece with one eyelet for each stud. The arm is secured in place using washers and hitch pins. The new arms are offset one inch outwards at the bottom mount.

*Hint: A hitch pin inserted in the mounting stud will make tightening easier. It is important to get the pin tight. If necessary, ViseGrip-type pliers can be used, but use a piece of leather or similar material to protect the stud's finish.*

**Tera Manufacturing, Inc.**  
5251 South Commerce Dr.  
Murray, Utah 84107  
Phone/801.288.2585  
Fax/801.713.2313  
[www.teraflex.biz](http://www.teraflex.biz)