



**907- Mountaineer Rack;**  
 Wrangler JK, 2007 to current Unlimited 4 Door.  
 907-171 Gloss Black  
 907-174 Texture Black  
 For assistance with installation please call  
 800 777 0878 mon-fri 9:00am to 3:00pm p.s.t.

**DO NOT TIGHTEN HARDWARE UNTIL ALL HARDWARE IS IN PLACE, OR INSTRUCTED TO DO SO.**

Parts	Hardware
2 - L shape brackets which make a Z Bar mounting bracket	6 - 3/8-16 x 5" carriage bolts
8 - Round Spacer Tubes	4-5/16" x 5 1/2" carriage bolts
1 - Top Loop	2- 3/8-16 x 6" carriage bolts
1 - Bottom Loop	8- 3/8" nylocks
6 - Knobs	12- 3/8" flat washers
2- Male/ 4 Female	Tools Required:
2 - Roll bar saddle brackets (C Brackets)	9/16" Socket
8 - Square Spacer Tubes	9/16" Open End Wrench
2 - Solid Rectangular brackets	1/2" Socket
	1/2" Open End Wrench
	3/8" Drive Ratchet



**Step 1: Constructing the basket**

A: Take the top loop of the basket and set it on a table or floor.  
 B: Insert the carriage bolts from the bottom up, place a flat washer over the bolt then slide the spacer tubes over the bolt and place a second flat washer over the end of the bolt to set on top of the spacer tube.  
 C: Take the bottom loop and place it over the bolt ends and fasten the nylock nuts with a 9/16" socket or wrench. As you fasten the nuts the carriage bolt head will seat itself into the round hole in the top loop.  
 (Tighten until head sits flush on top of rectangle)

**Step 2: Installing the Z Bar Mounting Bracket**

A: Bolt the two piece L Shaped Brackets together using a knob. To form a Z ( Z Bar )  
 B: Unfasten the O.E.M. Nut behind the rear passenger seat with a #18 m.m. socket or wrench. Place Z bar in position and refasten the same Nut into place.  
 C: Unfasten the nylock nut on the bottom of the basket that lines up with the hole in the top of the Z bar. Position basket on top of the Z bar. Place the bolt thru the Z bar and refasten the nylock. .

**Step 3: Installing Basket to Roll Bar**

(Installing the specialty hardware around the rear of the roll bar.)  
 A: Holding the rectangle spacer between the roll bar and the basket, insert the carriage bolts thru the inside of the lower loop of the basket.  
 B: Place a square spacer tube over each of the carriage bolts and then place the roll bar saddle bracket from the outside of the roll bar and slide two more square spacers over each of the bolts and fasten with the Knobs

Two piece Z Bar mounting bracket. With quick disconnect knob.

