



INSTALLATION INSTRUCTIONS REAR LIGHT SPACER BRACKETS '07 & UP JK & UNLIMITED - 1480

Read these instructions completely before starting your installation

1. Remove Spare Tire
2. Unplug wire for tail light – you need to open tailgate and remove plastic vent on driver's side
3. Unbolt and remove Spare Tire Carrier
4. Measure 3" up from the base for the light bracket and mark a line – Cut the Light Bracket on the line using hacksaw or die grinder. (It will cut easy because it is alloy)
5. Take new bracket and lay it on top of the old bracket and mark the hole approximately 1/2" from the edge of both pieces and drill holes.
6. Cut wires and splice in 5 inches of wire on each.
7. Remount Spare Tire Carrier, plug wire back in, pop vent cover back in place and mount Spare Tire.



Congratulations! You're done! Be sure to check out other fine Warrior Products on our web page, "warriorproducts.com"

"Your Knight in Shining Armor!"