

**IMPORTANT: Read And Understand All Instructions Before Installation • QUESTIONS? CALL 1-800-982-1180**

### BILLET ALUMINUM GEAR SHIFT KNOB

Time To Install: Approx. 10 Minutes



Begin by twisting the bottom boot of the shifter clockwise (Photo 1). Remove the torx head screw with a t-20 torx (Photo 2) and pull the stock shifter off (Photo 3). Place your new Billet shifter back in place (Photo 4). Align the set screw back up and tighten (Photos 5 and Photo 6).

### BILLET ALUMINUM 4WD GEAR SHIFT KNOB

Time To Install: Approx. 10 Minutes



Begin by setting the parking brake, placing the transmission in natural, and put the transfer case in natural or 4lo. With a firm pull, the stock shifter will come off (Photo 1). Place your new Billet Shifter into place and align for the set screw (Photo 2). Insert the set screw into the V-shape portion of the shaft and tighten (Photo 3).

**RealWheels Cover Company, Inc. • 3940 Tannahill Drive • Gurnee, IL 60031**

**847-662-7722 • Fax 847-662-7744 • www.realwheels.com • info@realwheels.com • toll-free 1-800-982-1180**