

## JK DOOR SLIDER KIT

### RS6214B Parts List

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
176540B	Left Slider	1
176541B	Right Slider	1
860644	Hardware Kit	1
	1/4-20 x 1.00 HHCS	8
	1/4 USS Washer	8
860653	Hardware Kit	1
	M8-1.25 x 40	4
	M8-1.25 Clip-on Nut	4
	USS Washer	4
	Thread Lock	1
88614	Instruction	1

### RS6215B Parts List

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
176543B	Left Slider	1
176544B	Right Slider	1
860652	Hardware Kit	1
	1/4-20 x 1.00 HHCS	10
	1/4 USS Washer	10
860654	Hardware Kit	1
	M8-1.25 x 40	6
	M8-1.25 Clip-on Nut	6
	USS Washer	6
	Thread Lock	1
88614	Instruction	1

- 1) If applicable, remove driver side OE side step. Save hardware for reuse.
- 2) Loosen the driver side body mount bolts. Insert left slider 176540B or 176543B between the washers and rubber mounts. See illustrations 1 and 2.
- 3) Install the supplied clip-on nuts if necessary.

NOTE: The clip-on nuts and 8mm hardware are not needed if an OE side step was removed.

- 4) Attach slider brackets to the body with the supplied hardware and original bolts (if applicable). See illustration 3. Tighten nuts and bolts to 18 ft. lbs.
- 5) Tighten the body mount bolts to 80 ft. lbs.
- 6) Repeat steps 1 through 5 to install right slider 176541B or 176544B on the passenger side.



Illus. 1



Illus. 2



Illus. 3