




Crown Automotive Sales Co., Inc. CJ Antenna Kit: Replaces Part Number: 82200683K & 8127842K

Kit Contents:

- 1 – Antenna Base Mount & Gasket
- 1 – Antenna
- 1 - Cable
- 3 – Screws & Plastic Caps



1. Ensure that all components in kit are accounted for.
2. Remove the antenna from the base mount and remove the cable from the back of the radio.
3. Unscrew the antenna base mount and remove it along with the gasket.
4. Clean the fender where the new antenna base mount will sit to prevent rust or corrosion.
5. Route the new cable from the radio to the new antenna base mount in a way that it will not interfere with any hot or moving parts. Plug the cable into the radio but don't reinstall until after the new antenna has been tested.
6. Slide the antenna cable through the gasket and connect it to the antenna base mount.
7. Once the antenna has been tested and the cable has been routed correctly, install with the provided screws. Do not over-torque.
8. Place the plastic caps over the ends of the screws. This will ensure that no moving parts come in contact and are damaged by the screws.

NOTE: If installing on a Jeep® without an antenna, use the provided template. It places the antenna in the stock location on the right cowl just behind the fender.

While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.

