



## **PART# 6032/6033**

'07- '11

JEEP WRANGLER

## **REPLACEMENT BILLET FUEL DOOR INSTALLATION INSTRUCTIONS**

---

### **YOU MUST DRILL IN THIS INSTALLATION**

1. Place your new billet aluminum gas door over the gas shroud. Make sure the door is level and the hinge side of the door is towards the front of the Jeep.
2. With a 9/64 drill bit, drill 3 holes in the plastic shroud using the holes in the ring as pilots.
3. Install 3 sheet metal screws using the square drive bit provided with the billet gas door. Tighten the screws evenly so you don't distort the plastic

NEED HELP? 916-933-0236 **AMI** 5121 HILLSDALE CIRCLE  
EL DORADO HILLS, CA 95762