

JEEP®
SINGLE STABILIZER KIT
INSTALLATION INSTRUCTIONS
Kit #: 7119



KIT CONTENTS:

- 1 - 7900WS Stabilizer
- 2 - 83161 Mounting Brackets
- 4 - Stem Bushings
- 2 - 142120 Washer/Nut Packs
- 2 - $\frac{5}{16}$ " x 1" x $2\frac{1}{4}$ " U-Bolts, Nuts, & Washers
- 2 - $\frac{5}{16}$ " x $1\frac{1}{4}$ " x $2\frac{1}{4}$ " U-Bolts, Nuts, & Washers

1. Place wheels in straight forward position.
2. Place boot onto stabilizer, but **do not** secure boot with boot tie at this time.
3. Install both brackets onto each end of stabilizer using bushing & washer packs provided.
4. Pull the stabilizer rod out EXACTLY half-way out. Stabilizer must be kept out exactly half-way during installation.
5. Mount stabilizer in place (refer to photo). Install U-bolts ($\frac{5}{16}$ " x $1\frac{1}{4}$ " x $2\frac{1}{4}$ " around track bar and $\frac{5}{16}$ " x 1" x $2\frac{1}{4}$ " around tie rod assembly), but **do not** tighten yet.

NOTE: Be sure the passenger bracket is located directly below the tie rod clamp (see arrow below.) After brackets are in position, tighten the U-bolts.

6. Turn wheels fully to the left & right to make sure stabilizer is adjusted properly (refer to step #4.)
7. Place boot tie around boot & secure.

