

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39464**

2009-07 Jeep Wrangle (JK) (2 Door) 3.8L
w/ Rock Crawler Type-Off-Road Suspension System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. exhaust from behind the catalytic converters. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install a 2½" band clamp on the inlet of **52366**. Install front intermediate pipe **52366** onto the outlet of the converter pipe. Insert the rod hanger into the rubber isolator.
3. Install muffler **17263**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the 53266 front pipe.

4. Install tail pipe **55428**. Be sure to insert the metal rod hangers into the rubber isolators. Slightly tighten the 2½" clamp that connects the tail pipe to the muffler outlet.
5. Install the DynoMax tip **36443** on the outlet of the tail pipe using a 2½" clamp.
6. Beginning at the inlet end, align the system components and fully tighten all the clamps.
7. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17263 MUFFLER
- (1) 52366 FRONT PIPE
- (1) 55428 TAIL PIPE
- (1) 36443 TIP
- (4) 2½" BAND CLAMPS
- (1) 709043 INSTRUCTION SHEET

39464 SYSTEM DIAGRAM

