

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39478**

2009-08 Jeep Cherokee 3.0L CRD Turbo V6 Diesel



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. or existing exhaust system. Lubricate the rubber isolators and fasteners with WD-40, or a similar product, to aid in removal. The OE system may need to be cut for ease of removal.
2. Install DynoMax front intermediate pipe **55487**. Insert rod hanger into the OE rubber insulator and slightly tighten the inlet flange fasteners. Place a 3" band clamp on the outlet end.
3. Install DynoMax over-axle pipe **53656**. Insert the rod hangers into the OE rubber insulator. Slightly tighten the 3" inlet band clamp and place a 2¾" band clamp on the outlet end.
4. Install DynoMax Ultra Flo Welded muffler assembly **17566**. Insert the rod hanger into the OE rubber isolator and slightly tighten the inlet band clamp to the over-axle pipe. Place a 2½" band clamp over the outlet end.

5. Install the DynoMax SS tip **36443**.
6. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
7. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17566 MUFFLER
- (1) 55487 INT. PIPE
- (1) 53656 OVER-AXLE PIPE
- (1) 36443 SS TIP
- (1) 2½" BAND CLAMP
- (1) 2¾" BAND CLAMP
- (1) 3" BAND CLAMP
- (1) 709046 INSTRUCTION SHEET

39478 SYSTEM DIAGRAM

