


Installation Instructions
Part No. 30542 & 50542
Mirror Relocation Brackets
Fits 2003-2006 TJ Jeep



Carefully remove the two bolts on the lower part of the windshield hinge. Position and mount the relocation bracket using the 5/16" bolts provided. Remove the factory mirror from the door and mount the mirror to the bracket using 1/4"-20nc bolts and nuts provided. Make sure all bolts are securely tightened. With help adjust the mirrors to your needs. **We recommend that you use anti sieze on all threads of the stainless bolts provided with your parts.**

Note: The relocation brackets are designed for use with the doors off. The doors will hit the mirror if you try to drive the Jeep with the doors on. Remove the bottom plastic from the mirror as it will fall off during use.

Installation Instructions
Part No.30542 & 50542
Mirror Relocation Brackets
Fits 2003-2006 TJ Jeep



Carefully remove the two bolts on the lower part of the windshield hinge. Position and mount the relocation bracket using the 5/16" bolts provided. Remove the factory mirror from the door and mount the mirror to the bracket using 1/4"-20nc bolts and nuts provided. Make sure all bolts are securely tightened. With help adjust the mirrors to your needs. **We recommend that you use anti sieze on all threads of the stainless bolts provided with your parts.**

Note: The relocation brackets are designed for use with the doors off. The doors will hit the mirror if you try to drive the Jeep with the doors on. Remove the bottom plastic from the mirror as it will fall off during use.