

## Installation Instructions

For

30655 and 30656

Fiberglass Front Fenders

Fits 1997-2006 TJ Jeeps

Remove all components bolted to the fender.

In order to align the front fender with the Body you must remove the battery and the battery tray. On the passenger side.

You may also have to remove the tray on the support bracket on the driver side.

The fender should then go directly up against the Firewall and the support bracket on both sides. The front of the fender bolts to the grill in two locations.

Start all bolts then check for alignment of the fender with the Hood and the body. Make any adjustments then tighten all bolts.

Reinstall the battery tray and the battery. Reinstall the tray On the driver side. Reinstall all components to the fender.

## Installation Instructions

For

30655 and 30656

Fiberglass Front Fenders

Fits 1997-2006 TJ Jeeps

Remove all components bolted to the fender.

In order to align the front fender with the Body you must remove the battery and the battery tray. On the passenger side.

You may also have to remove the tray on the support bracket on the driver side.

The fender should then go directly up against the Firewall and the support bracket on both sides. The front of the fender bolts to the grill in two locations.

Start all bolts then check for alignment of the fender with the Hood and the body. Make any adjustments then tighten all bolts.

Reinstall the battery tray and the battery. Reinstall the tray On the driver side. Reinstall all components to the fender.