



CFE PRODUCTS

3rd BRAKE EXTENSION KIT

MODEL #TJ-3RDBLR



Jeep Wrangler ,YJ & TJ / 1992 to 2006



INSTALLATION INSTRUCTIONS

1. Remove the Spare Tire.
2. Remove the 4 Bolts that attach the Third Brake Light to the Spare Tire Carrier.
3. Using the same 4 Bolts that were just removed, attach the Brake Light Risers with the Slotted Side facing Up to the Spare Tire Carrier (there is a left & right). Refer to pictures 1 & 2.
4. Using the (4) 5/16 Nuts & Bolts supplied with the Kit attach the Third Brake Light to the Riser Mount as shown in pictures 2, 3 & 4. The Slots in the Riser allow for Depth adjustment of the Third Brake Light to accommodate different tire sizes. (the SAFEST Position is to adjust the Third Brake Light as close to the Tailgate as possible)
5. Reinstall the Spare Tire.

