



PRO COMP SUSPENSION, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

Part # 55297/55298 Jeep Wrangler TJ 1.5 - 2.0 Replacement Coil Kit

⇒ **PLEASE READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE YOU BEGIN INSTALLATION.**

To properly install replacement coil kit the following part numbers are needed.

PARTS LIST:

ITEM#	DESCRIPTION	QTY.
55297	Front Coils	1
55298	Rear Coils	1
321515	Front Shocks	2
321500	Rear Shocks	2

NOTE: Pro Comp also suggests replacing steering stabilizer with part #219200.

NOTE: Installation of pinion angle cam kit #20-65225 maybe required to adjust rear pinion angle.

Front Disassembly:

- 1) Block rear tires and raise front of vehicle with floor jack or other suitable means.
- 2) Support chassis with jack stands behind front lower control arm mounts.
- 3) Remove wheels, spring retaining clips, front shocks, and sway bar end links.
- 4) Lower front axle and remove coils.

Front Assembly:

- 1) Install new coils part **#55297** shocks, coil retaining clips, sway bar end links and tires.
- 2) Lower vehicle to ground.

Rear Disassembly:

- 1) Block front tires and raise rear of vehicle. Support chassis with jack stands in front of rear control arm mounts.
- 2) Remove tires.
- 3) Remove shocks and lower rear axle.
- 4) Remove rear coils.

Rear Assembly:

- 1) Install new rear coils part **#55298** and raise axle.
- 2) Install rear shocks (NOTE: Crosspins included in part **#55298** are for the rear upper shock mount when using Pro Comp shocks).
- 3) Install tires and lower to ground.
- 4) Check all hardware for tightness.
- 5) Have vehicle aligned.