



CFE PRODUCTS

TJ CUSTOM HEAVY DUTY BATTERY TERMINALS

MODEL #TJ- HDBT

Jeep Wrangler CJ, YJ, TJ thru 2006



Kit Includes:

- (2) 1/4-20 Stainless Steel Battery Bolts
- (2) Stainless Steel Accessory Power Taps
- (2) 5/16th Heavy Duty Brass Power Tap Nuts

Whenever working on your battery, always disconnect the Negative Terminal First.

1. Disconnect the Negative Battery Terminal (black wire).
2. Remove both Battery Bolts from the Positive & Negative Terminals and Remove both Terminals from the Battery.
3. Make sure your Battery Terminals are clean and install the Battery Terminal Protectors included in the kit. Red goes to Positive Terminal and Green/Black goes to Negative Terminal.
4. Using the New Stainless Steel Bolts, Install the New Heavy Duty Battery Accessory Terminals as shown in the picture below.

Accessory Terminals

Terminal A: (Brass Extension Nut 5/16th thread) This Terminal is for High Current Accessories (example Winch)

Terminal B: (Stainless Steel Terminal 1/4-20 bolt) This Terminal is for Med/Low Current Accessories. (example Running Lights or Audio Equipment)

