



CFE PRODUCTS

JK CUSTOM HEAVY DUTY BATTERY

TERMINALS

MODEL #JK- HDBT

Jeep Wrangler JK / 2007 & UP



Whenever working on your battery, always disconnect the Negative Terminal First.

1. Disconnect the Negative Battery Terminal and remove the Factory Wires from the Terminal (black wire).
2. Remove the Positive Battery Terminal and remove the Factory Wires from the Terminal (red & green wires).
3. Make sure your Battery Terminals are clean and install the Battery Terminal Protectors included in the kit. Red goes to Positive Terminal and Green goes to Negative Terminal.
4. Install the New Heavy Duty Battery Terminals. Pay Attention...the Battery Terminal with the 3/8ths Stud (picture A) is the Positive Terminal. The Battery Terminal with the 5/16th Stud (picture D) is the Negative Terminal.
5. Reattach the Factory Battery Cables to the New Negative & Positive Terminal Bolts as shown in position B.

Note: Position B is on both terminals is reserved for the Factory Cables Only.

Accessory Terminals

Terminal A: This Terminal is for High Current Accessories (example Winch)

Terminal C: This Terminal is for Med/Low Current Accessories. (example Running Lights or Audio Equipment)

