



Warrior, Inc.
11100 SW Industrial Way
Tualatin, Oregon 97062
(503) 691-8915 Main
(503) 692-0364 Fax
(888) 220-6861 Toll Free
techsupport@warriorproducts.com

SUBJECT: INSTALLATION INSTRUCTIONS: 2350 License Plate Fairlead Mount

1. Begin by unpacking your kit. You should find a mount plate, two clip mechanisms, and an assortment of bolts and nuts.
2. Use the supplied four bolts and nuts to install the clip mechanisms to the mount plate. These clips mount on the back side of the plate, opposite the threaded studs.
3. With the clip mechanisms bolted up and tight, slide your license plate over the 4 threaded studs.
4. Affix a flat washer, external lock washer, and then an acorn nut to each stud.
5. Your mount is now full assembled and can now be installed and uninstalled from your roller fairlead by simply pressing it into place.

For more information on Warrior Products Jeep Parts and Accessories, please visit us on the web at www.warriorproducts.com

