



## PPM-5807 YJ FRONT GRAB HANDLE KIT

Version 1.0

### GENERAL NOTES:

- Read installation instructions fully prior to beginning installation.
- Check our website at [www.polyperformance.com](http://www.polyperformance.com) for updated instructions.
- The installation of these handles can be done with the top on or off.
- The grab handle kit is a bolt on installation but you do have to trim some of the roll bar padding and covering if your Jeep is equipped with it.



Complete PPM-5807 TJ Front Grab Handle Kit

- 1) Begin by removing the roll bar padding / covering if your YJ is still equipped with it.
- 2) Next, remove the outer, lower torx head bolt which connects the windshield to the roll bar.



Outer Torx head bolt removed.



- 3) Install grab handle as shown. Do not tighten bolts just yet, get them finger-tight.



- 4) Once both mounting points have been started, tighten the torx head bolt at the windshield to 20 ft-lbs. Then snug down the J-Hook bolt. Be careful not to over-tighten and strip out J-hook or button head screw.

- 5) Reinstall roll bar padding and covering if still equipped. Trim as necessary for finished installation.



Fully installed YJ raw steel handle.