

OVH Storage Console

Contents:	Quantity
Storage Console	(1)
Mounting Brackets	(2)
M8 Bolt	(4)
M8 Flat Washer	(4)
M8 Nut	(4)
Long Velcro Strap	(4)
Short Velcro Strap	(1)



1. Locate the mounting holes at the ends of the Storage Console. Position Mounting Bracket above the mounting holes with the slots facing forward. Attach the Mounting Bracket to the Storage Console using the supplied M8 hardware.



2. Place the Storage Console inside the vehicle such that the mounting brackets rest on the roll bar. The Storage Console should sit just above the visors. Insert Long Velcro Straps through the slots in each Mounting Bracket and strap them tightly around the roll bar on both sides of the vehicle.



3. Insert the Short Velcro Strap through the slot in the rear of the Storage Console and attach to the footman loop of the windshield.



For assistance, please contact Omix-ADA Technical Support department
(770) 614-6101
techsupport@omix-ada.com