

Trail Kitchen Accessory: **JP54-039**

MOLLE GRID BRACKET

INSTALLATION INSTRUCTIONS

Tools Needed:

7/16" Wrench

5/32" Allen wrench



STEP 1

Line up the holes in the MOLLE Bracket with the holes in the fridge tray.



STEP 2

Using the supplied 1/4 -20 button head bolts and nuts, fasten the MOLLE Bracket to the fridge tray.

MORryde

HEAVY. DUTY. ADVENTURE.

www.MORryde.com • 574.293.1581