

Roll Bar Accessories Installation Instructions

#RB-1 Dome Light model: Mount on horizontal part of roll bar.

#RB-2 Utility Hook model: Mount on vertical side portion of roll bar.

#RB-3 Universal Mount model: Mount on any straight portion of roll bar.

1. Feed tie straps through cradles on back of mount.
2. Hold unit in desired position on roll bar and push ends of straps through buckles. Tighten tie straps. Make sure both straps are tightened securely.
3. Leave approximately 2 inches of extra tie strap and cut off the rest. Push the remaining end through extra loop on buckles so that it does not protrude. This will give the installation a smooth, clean appearance.
4. Roll bar accessories may be removed for cleaning or re-positioning by depressing tab on buckle with a screwdriver. This will release tie straps.
5. On RB-1 Dome Light model, the black wire should be connected to a positive (+) 12 volt source, and the white wire to a negative (-) vehicle ground. No wire harness is included with the light due to variations in vehicle wiring systems. Any necessary wiring can be done with 18 gauge automotive-type insulated wire. For a clean appearance on padded roll bars, wires can be concealed under padding. If weather-resistance is needed for no-top vehicles, simply seal around wire exit hole on light backing plate with silicone sealer. The Dome Light uses a standard automotive #1141 bulb which can be easily replaced by removing the screws that hold the lens in place. When re-installing lens, do NOT over-tighten screws.
6. On RB-3 Universal Mount, 2 carriage bolts with nylon anti-vibration washers are included. These can be used to mount a fire extinguisher, first aid kit, small audio speaker, or similar item. Slotted holes are provided to hold the bolts and will match up with almost any hole spacing. If the included bolts are too long or short they can be cut or other bolts can be substituted. Because of the variety of accessories that can be mounted, you may want to use a different style bolt or even place the nuts on the roll-bar side of the mount. In any case, make sure that the fasteners do not touch the roll-bar or roll-bar padding when the mount is installed. Your local hardware store can supply any type of bolt for attaching almost any accessory.

NOTE: On all soft-top vehicles, make sure that ends of ties and edges of metal mounting plate do NOT touch fabric of top.

LIMITED WARRANTY

This product is guaranteed against defects in materials and workmanship for one year from date of purchase. Just return to us with an explanation of reason for return and unit will be repaired or replaced at our option. There are no other warranties either expressed or implied beyond those set forth in this warranty. The manufacturer is not responsible for any consequential or incidental damages. (Some states do not allow the exclusion of consequential or incidental damages so the above exclusion may not apply to you.) This warranty gives you specific legal rights and you may also have other rights which vary from state to state.