



#1= Position the tube clamps **09** around existing Safari Rack side bars, at desired locations, ensure they are straight across from each other. Then insert bolts **A** with flat washers **B** up through lower clamp **09**, and secure with lock washers **C** and nuts **D**. Leave bolts loose for final adjustments of rack.

#2= Position Yakima cross bars and bolt on top clamps **09** with bolts **A** and flat washers **B**. Secure loosely with lock washers **C** and nuts **D**. Center cross bars so you have equal distance from each tube end cap to each top tube clamp **09**.

After final positioning of rack, tighten ALL bolts. **THAT'S IT!** Your installation is complete.

**NOTE:** If you experience any wind noise, it may be necessary to relocate your existing Yakima cross bars forward or backward.

### HARDWARE KIT FOR YAKIMA MOUNT

Shown Actual Size

