

## SAFARI RACK INSTRUCTION SHEET

1. Put frame of basket rack together first. You are provided with four L shaped pieces. The two short pieces are the front and back of the basket rack frame and the two longer ones are the sides. These pieces can easily be put together by sliding the square tube into the stanchion. Do this to all four sides. Once all these sides are put together tighten sides up with the #10x3/8 sheet metal screws provided.

2. Once the frame of the basket is put together, place side rails on top of angles with ridges facing up. Using 1/4-20x5/16 screws tighten siderails to angles.

3. Slide seven special nuts into each crossbar, placing three in the center and two on each side. Line the three center nuts with the slots in the side rails. If these slots are not in the desired position you can redrill your own holes. Make sure that the crossbars are centered from side to side. Place bracket (1) over square tubing and align holes on the bracket to the holes on the special nut. Use provided 1/4-20x3/8 and tighten all the sliding nuts.

### PART LIST

- |    |                            |
|----|----------------------------|
| 4  | (1) brackets               |
| 8  | #10x3/8 sheet metal screws |
| 26 | 1/4-20x3/8 screws          |

