

RIVER RAIDER

LJ

HIGH LIFT JACK MOUNT INSTRUCTIONS

- 1. Tap the factory holes on the Jeep roll cage using enclosed 1/2" tap and a wrench. Be sure to start the tap straight in the hole to ensure good threads. As the tap cuts the threads it will get tight. Reverse the tap out a turn and then go back in until the threads are fully cut.**
- 2. Using the supplied 3/4" bolts and washers, attach the hi-lift jack mounts to the roll cage. Liquid thread lock is recommended on these bolts.**
- 3. Remove the factory bolt from the head of your hi-lift and replace it with the enclosed 2" bolt. This bolt will hold your hi-lift to the jack mount using the supplied washers and wing nut.**
- 4. Attach the foot of the hi-lift jack to the mount with the supplied 1" bolts, washers, and wing nut. Due to irregular foot castings some hi-lift jacks may require drilling to fit properly.**



