



CFE PRODUCTS

MODEL # JK-CBFMAK

Jeep JK Wrangler Fender Mount CB Antenna Kit

2007 & UP



INSTALLATION INSTRUCTIONS

1. The Fender Mount is designed to be installed on the driver's side.
2. Remove the bolt as shown in picture #1 using a 10mm socket.
3. As an optional precaution to prevent scratching of the paint, turn the mount upside down and put a piece of black tape along the bend as shown in picture #2.
4. Install the mount using the screw supplied in the kit with a 10mm socket as shown in picture #3. This screw is not painted and will ground the mount to the fender.
5. Run the cable into your Jeep using the hole in the firewall as shown in picture #4. You will need a small razor knife to put a slice in the insulation. Pull as much wire as you need inside the Jeep. Leave the extra wire under the hood and strap it up along the fender in long loops as shown in picture #5 using the tie straps supplied. Do not attempt to shorten the cable, the length is critical for proper antenna operation. Do not curl the wire up in a ball as this can have a negative affect on the systems performance.
6. After the antenna is installed, you can use the two 1/4 - 20 bolts to adjust the antenna so that it is straight as shown in picture #6.

Parts Included:

1. Custom Stainless Steel Fender Mount
2. Low Profile 18 ft. Cable
3. Custom Wound 3ft Super Flex Antenna
4. One 6mm Fender Bolt
5. Three Tie Straps

Your New Antenna is custom wound and pre-tuned to match your Jeep. No further adjustment is necessary.

