

Hypertech Speedometer Calibrator Installation Instructions PN 752504 2018 Jeep Wrangler JL

This installation manual shows an example installation on a 2018 Jeep Wrangler JL with a 3.6L engine. The installation may vary for your vehicle, so it may be necessary to consult the service manual for your year model.

Tools Needed: Flashlight

Be advised: These instructions may not include specifics for all vehicle configurations.

1. This step makes sure that the programmer has the latest firmware installed. If Tuner Update Software is not already installed on your PC, go to our website and download the update software. Connect the Speedometer Calibrator to your PC with the supplied USB cable, run the update software and click the Update Tuner button. You may be prompted to select the correct configuration file for your vehicle. Once configuration is complete, take the Speedometer Calibrator, harness, USB-cable and 12-volt adapter to the vehicle.



2. ** Make sure the ignition switch is in the OFF position **

3. Open the glove box and locate the damper on the left hand side of the glove box.



4. Lift the damper gently where it meets the glove box, until a snap is heard. Pull the damper to the left to remove from the glove box.
5. Locate the stop in the middle of the back of the glove box. Push the stop toward the front of the vehicle while gently lowering the glove box.



6. Remove the glove box.

7. Insert the small, white connector into any open slot on the green junction block.



8. Join the male and female ends of the Diagnostic Connectors together. Attach the rectangular plug into the bottom of the Speedometer Calibrator.
9. Insert the micro-USB connector into the Speedometer Calibrator and the USB-male-A connector into adapter. Plug the adapter into the cigarette lighter.
10. Place the ignition in the RUN position by pressing the Start button twice with foot **off** of the brake and follow the on-screen instructions.

11. When programming is complete, the Speedometer Calibrator will ask you to turn the ignition key to OFF and disconnect the cable. Remove all cables installed in Steps 8 and 9.

12. Align the hinge on the bottom of the glove box with the dash.



13. Push the glove box until the glove box stop latches

14. Insert the damper into the hole on the left side of the glove box and push the damper down until a snap is heard.

15. Close the glove box.