

ROLL TOP DASH TRAY

PART # 31800 - 2011-CURRENT JK WRANGLER

Please read instructions before beginning installation.

Be sure you have all tools required before you begin.

NOTE: Park vehicle on a level surface

Tools Required

7mm Nut Driver
or 7mm Socket & Ratchet

Parts List

(1) Roll Top Dash Tray
(1) Insert



1) Remove Rubber Insert



2) Remove 7mm Hex Screw



3) Place Dash Tray into Dash



4) Re-Install Hex Screw



5) Installed

VDP - Vertically Driven Products

1401 Freeman Ave., Long Beach, CA 90804

Tel: (562) 438-5112 Fax: (562) 439-6792

info@vdpusa.com

Part # I/31800 - Feb. 2015

31800 Roll Top Dash Tray.xls