



EVO-1121B

07+ Jeep JK Evap Skid



<u>Part#</u>	<u>Description</u>	<u>Qty</u>
EVO-12057B	Evap Main Skid	1
EVO-12058B	Evap Skid Rear Mount	1
EVO-770048	EVO Evap Hardware Pack	1

Installation photos shown are on a 2012 + Jeep Wrangler JK, for those installing the EVO Evap Skid on a 07-11 Jeep JK follow the same install procedures.

NOTES PLEASE READ BEFORE INSTALL

Keep All Mounting Bolts loose until all bolts are installed into place. Then tighten all bolts. Throughout the install there is no need to remove any of the factory hoses or factory evap mounting bracket. You will only be required to remove the factory bracket from the crossmembers.

1. Loosen the two factory front evap skid bolts so that about $\frac{1}{4}$ " thread are showing.



2. Loosen and remove the rear factory evap skid bolt completely.

3. Loosely install the EVO-12058B Evap Skid Rear Mount Plate using the rear factory evap skid bolt , the rear mount plate should be installed so that the plate is sandwiched between the crossmember and factory evap bracket, leaving yourself a few threads still showing.
4. Remove the two factory front evap skid bolts you previously loosened in step #1. Note the factory evap skid bracket will now be supported by the rear bolt only. You are now ready to install EVO-12057B Evap Main Skid Plate. Start by placing the front lip of the factory evap skid under the front edge of the EVO Evap Main Skid. Once you have done this



the rear of the factory evap skid can be nestled into the rear of the EVO Evap Main skid.

5. Loosely secure the front of the EVO Evap Main Skid with the two factory front evap bolts, leaving a few threads showing.



6. Install the supplied hardware tightly securing the EVO evap main skid to the EVO evap rear mount plate.



7. Tightly secure the two factory front evap bolts and the one factory rear evap bolt.

