

CFE PRODUCTS TJ CUSTOM LIGHT MOUNT BRACKET MODEL #TJ -LED LMB



Jeep Wrangler TJ / 1997 to 2006









Installation Instructions

- 1. Remove the two Bumper/Tow Hook Bolts on both sides as shown in picture #1.
- 2. Loosely install the Light Mount Brackets with the Light Mount holes facing the center of the Jeep as shown in picture #3.
- 3. Adjust the distance between the Brackets to match your LED Light Bar and tighten Bumper/ Tow Hook bolts.**
- 4. Install LED Light Bar.
- **Depending upon the size of your Light Bar, the Tow Hooks can be swapped to the opposite side ensuring that the Light does not block the use of the Hook.

