

CLOVER PATCH Inc. WINDOW ROLL™ INSTRUCTIONS

Pat. Pending #60/420,912

1. Lay the felt wrap on a clean flat surface and place the rear window, with the bar attached, as shown below. Place the end with the bar next to the closed end of the felt divider. Cover the rear window with a felt flap. The windows must be clean prior to storage. Use the hood of the Jeep if there is not a clean area for the felt.



2. Place the quarter (Side) windows above the rear window bar and cover each with a felt flap as shown below. Insure that the windows are clean prior to storage.



3. Roll the three windows up starting at the OPEN end of the felt flaps. Wrap the straps around the window roll. This will hold the windows in the rolled position as shown. Do not roll the windows tightly as there is ample room in the nylon bag for the windows.



4. Insert the window roll into the outer bag and close the draw strings on each end. Lay the bag (Generally seam down is best – tag on driver's side) on top of the folded down

top, or across the tub if the top is up, and buckle the bag to the roll bar. Do not pull the straps too tight, just snug. Tuck the excess strap back under the strap around the roll bar as shown below. Insure that the straps do not go over or interfere with the rear seat belts. Tug on the straps and adjust the buckles so that the straps do not loosen. Check the straps from time to time to insure proper operation.



5. The outer protective bag should fit snugly around the window roll felt as not to cause any flapping. During hot weather the windows may flatten some on top. This is considered normal and does not harm the windows. If excessive, move the straps around the felt, to the center. Check the buckles from time to time to insure the bag is secure.

Spare parts for the Window Roll are available from Clover Patch. Please keep these instructions.

The window roll carries a 90 day limited warranty against all workmanship and material. The warranty does not cover damage or failure caused by improper installation, accident or misuse. Do not place objects on top of the window roll. The Window Roll is water resistant; however never leave windows in the Window Roll when wet. Additional exclusions apply.

We at Clover Patch take great pride in customer satisfaction. Please contact us with questions or comments at:

Clover Patch Inc.
5706 Clover Dr.
Crestwood, KY 40014
Phone: 502-241-3026
Fax: 502-243-3267
E-mail: cloverpatch@insightbb.com