



INSTALLATION INSTRUCTIONS

PART No.

FB31058

**Jeep® TJ Wrangler
BackSide Plate**



REQUIRED TOOLS

½" Socket

KIT CONTAINS

BackSide plate
Plastic plug

QTY

1
1

1) REMOVE YOUR SPARE TIRE

Begin by removing your spare tire or other aftermarket accessories from your tailgate.

2) INSTALL BACKSIDE

Using the four (4) OEM bolts and the ½" socket, install the BackSide plate to your Jeep.



3) INSTALL PLUG

Insert the provided plug into the hole for the factory 3rd brake light harness.



4) ENJOY YOUR NEW FISHBONE OFFROAD BACKSIDE!

3105800