

180- Auxiliary Bar

Use the 180- Auxiliary Bar to add auxiliary headlights, mount a Hi-lift jack, or numerous other types of off-road gear to an OEM bumper or one of Olympic 4x4 Products many heavy-duty front bumpers. Use as a bumper under rider by mounting 180-Auxiliary Bar under the bumper, providing protection of steering box. Made from 1 ½" X .065" wall round steel tubing, easily mounts to pre existing mounting holes on Wrangler TJ 1997- 2004. Olympic 4x4 Products are serviced by our factory. We provide answers to installation questions. We ship parts ASAP. Try us before the hassle of returning Olympic 4x4 Products to your retailer or mail order specialist.

For assistance please call (800)777-0878.



180- Auxiliary Bar with Hella HID 10" driving lights mounted on 543-50" Rock Receiver Bumper

Tools required:

3/8" or 1/2" drive ratchet wrench
#55 Torx bit socket

- Step 1. Remove the top bumper mounting hardware; this consists of four (4) #55 torx bit bolts.
- Step 2. Install the 180- Auxiliary Bar by placing auxiliary bar on top of bumper and lining up the mounting holes with the holes in your front bumper. If using to install auxiliary lights have the tabs pointing towards the jeep, and if using to mount a Hi-Lift jack, have the tabs facing away from the jeep.
- Step 3. Secure 180- Auxiliary Bar and front bumper with the OEM #55 torx bit bumper mounting bolts you removed in step 1.
- Step 4. Install auxiliary driving lights of your choice, or mount your Hi-lift jack using optional 181-Hi-lift jack mounting kit, that includes (2) threaded knobs, (4) 3/8" flat washers, (2) 3/8" lock washers, and (2) 3/8" nuts.



180- Auxiliary Bar mounted as an under rider on 530-57" Rock Bumper



180- Auxiliary Bar with Hi-lift jack mounted on OEM bumper Using 181-Hi-Lift jack mounting kit.