High Performance Cold Air Intake Kit



INSTALLATION INSTRUCTIONS

75-1518-1

Jeep Cherokee L6-4.0L

QTY PARTS LIST

- 1 2.75"-2" Adapter
- 1 1/2" x 7" Hose
- 1 Intake Tube
- 1 Intake Box
- 1 Intake Lid
- 1 CARB Sticker
- 1 Instruction Sheet

QTY PARTS LIST (continued)

- 2 #44 Hose Clamps
- 4 #10 Sealing Washers
- 4 SS Pan Head Screws

TOOLS REQUIRED

13mm socket & wrench

Flat head screwdriver


Phillips head screwdriver

Turn off engine and disconnect negative battery terminal. Loosen the hose clamp at the throttle body and unclip the stock air box



Attach the hose adapter to the S&B cold air







Unbolt the stock air box and remove



Install the S&B cold air tube thru the S&B cold air box and onto the throttle body



Install the S&B high performance filter. "Push the filter up until it contacts the inside wall of the air box and tighten



Bolt the S&B cold air box to the fender wall. "Place the stock air box grommets underneath the air box". Use the stock



Loosen the 3 nuts that hold the stock air. box to the fender well of the vehicle.



Attach the air box lid to the air box. Installation is complete. Check all mounting points for tightness and reconnect the battery







PERFORMANCE TESTING

- Engage parking brake and start your engine. To ensure that the system was installed properly, listen for abnormal noises. If an air leak is detected, re-inspect hoses and connections as they may need to be tightened.
- * S&B FILTERS RECOMMENDS THAT YOU KEEP YOUR OEM INTAKE SYSTEM IN THE EVENT IT IS REQURIED IN THE FUTURE.
- In order to maintain proper warranty, all connections and components must be checked periodically for realignment and to tighten all connections. Failure to do so will void your warranty.
- Use only S&B cleaning and oil products to service your filter. Using other company's oil and cleaner products may void your warranty.

Please call (909) 947-0015 should you have any questions or comments.