



BILLET CANDY FOR YOUR RIDE

PART# 6031

'97- 2006

JEEP WRANGLER

**REPLACEMENT
BILLET FUEL DOOR
INSTALLATION INSTRUCTIONS**

1. Remove the 4 Phillips screws from the plastic gas shroud.
2. Place your new billet aluminum gas door over the gas shroud.
3. Install 4 sheet metal screws using the square drive bit provided with the billet gas door.

- NO DRILLING REQUIRED -

NEED HELP? 916-933-0236 **AMI** 5121 HILLSDALE CIRCLE
EL DORADO HILLS, CA 95762



PART 1

97-2002

REPLACEMENT

DEPARTMENT OF HEALTH AND HUMAN SERVICES

1971

1. Remove the 4 Phillips

screws and discard.

2. Place your new filter in position as shown.

Over the top.

3. Tighten the metal screws on

top and bottom. Tighten

clockwise.

DEPARTMENT OF HEALTH AND HUMAN SERVICES

UNITED STATES GOVERNMENT

OFFICE OF THE SECRETARY