



Protecting Your Adventure Lifestyle

Warrior Products, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone (888) 220-6861  
Fax (503) 692-0364  
sales@warriorproducts.com

---

## **CJ5, CJ7, TJ, YJ REAR BUMPER** INSTALLATION INSTRUCTIONS

### **WAR 500, 505**

Bumpers are designed to fit over existing rear cross member support.

1. Remove old bumper or “Bumperettes” from vehicle.
2. Be sure that area where bumper will be mounted is flat and free of any damage.
3. Some TJ’s only have two pre-drilled (2) holes on each side. If you are installing a bumper on a TJ, you may need to drill two (2) additional holes on each side. Measure from existing holes; mark with a center punch and drill with a 7/16” drill. Be very careful not to drill into anything that may be behind cross member support. I.e. gas tank cover, wiring. Wear safety glasses.
4. Install new bumper with enclosed hardware. Tighten 7/16” nuts to 50 ft/lbs. Re-torque after your initial test drive.
5. If you have a hitch bumper, check the bumper bolts for tightness prior to and after each use.

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**