



**JEEP TJ Pillar Mount
Gauge pod
PART NO 17501
FITS ALL JEEP TJ FROM
2003-2005**

KIT INCLUDES:

- 1ea. GAUGE POD
- 1ea. Alcohol swab

PRIOR TO INSTALLATION

▲ The ambient air temperature (the temperature of the vehicle, body panels, and Trailready® gauge pod) must be between 60°- 110° F. This is critical in order for the 3M® brand VHB tape to properly adhere per the manufacturers specifications. Failure to follow these guidelines will result in poor adhesion and possible panel loosening.

1. Dry fit the pod as you proceed with the installation. Note the tape line position. These areas must be cleaned with a degreaser such as the supplied rubbing alcohol to ensure proper adhesion.
2. If you plan on painting your Trailready® Gauge Pod it must be done prior to installation. All surfaces must be cleaned using a scuff type sanding paste and prepped using an adhesion promoter. Follow all specifications required by the paint manufacturer
3. Fit and install your gauges into the gauge pod following the instructions included with the gauges you purchased. This must be done **BEFORE** you begin the Gauge Pod installation process.

Note: This pod only accommodates 2" to 2 1/16" gauges. Any attempt to install other than these size gauges will void your warranty. Run all the wiring and cables necessary for the gauges to operate.

INSTALLATION INSTRUCTIONS

1. Pre fit the gauge pod at the lower end of the plastic door trim closest to the dashboard. Note the tape line position. Once you are familiar with how the pod should look once installed proceed to the next step.
2. Clean the tape line area with the supplied alcohol swab (**All tape areas must be cleaned as described ▲ above**)
3. Peel red vinyl backing from tape.
4. Position the pod on the plastic door stop and trim. Align the edges of the pod to the door stop for best fit. Take care not to exert pressure on the adhesive tape before you have aligned the pod properly. Once you are satisfied with the location and fit of the pod apply firm pressure to the areas of the parts opposite tape pads to ensure proper tape adhesion. (See ▲ above)

The name's and logo's TAG The Accessory Group, Trailready, Boggyguard and Proguard are © & ® by TAG The Accessory Group Inc. All rights reserved. This product is warranted to be free from defects in material and workmanship for 90 days from original purchase date if properly installed, and subject to normal use. Improper installation procedures, alterations, misuse and abuse of this product will void all stated warranty provisions. Products returned and deemed to be covered by warranty will either be replaced with said merchandise or issued credit for same. TAG The Accessory Group Inc. 1025 Segovia circle Placentia Ca. 92670 714-630-6675