



**Gauge/Switch pod  
PART NO 17512  
FITS ALL JEEP TJ FROM  
1997-2005**

**KIT INCLUDES**  
**1ea. GAUGE POD**  
**1ea. Alcohol swab**

## **PRIOR TO INSTALLATION**

- ▲ The ambient air temperature (the temperature of the vehicle, body panels, and Trailready® gauge/switch pod) must be between 60° - 110° F. This is critical in order for the 3M® brand VHB tape to properly adhere per the manufacturers specifications. Failure to follow these guidelines will result in poor adhesion and possible panel loosening.
1. Dry fit the pod as you proceed with the installation. Note the tape line position. These areas must be cleaned with a degreaser such as the supplied rubbing alcohol to ensure proper adhesion.
  2. If you plan on painting your Trailready® Gauge/switch Pod it must be done prior to installation. All surfaces must be cleaned using a scuff type sanding paste and prepped using an adhesion promoter. Follow all specifications required by the paint manufacturer
  3. Fit and install your gauges/switches onto the Gauge pod following the instructions included with the items you purchased. This must be done BEFORE you begin the Gauge Pod installation process. Run all necessary wiring and cables to your gauges at this time.

## **INSTALLATION INSTRUCTIONS**

1. Pre fit the pod on the lip of the tray in the center of the Jeep dashboard. Note the tape line position. Once you are familiar with how the pod should look once installed proceed to the next step.
2. Clean the tape line area with the supplied alcohol swab (All tape areas must be cleaned as described ▲ above)
3. Peel red vinyl backing from tape.
4. Position the pod on the lip of the factory tray. Align the outer edge of the pod with the edges of the dashboard tray. Take care not to exert pressure on the adhesive tape before you have aligned the pod properly. Once you have checked for proper location apply firm pressure to the areas of the parts opposite tape pads to ensure proper tape adhesion. (See ▲ above)

The name's and logo's TAG The Accessory Group, Trailready, Bogyguard and Proguard are © & ® by TAG The Accessory Group Inc. All rights reserved. The TAG Trailready Gauge Pod is warranted against defects for 90 days from date of manufacture. This product is warranted to be free from defects in material and workmanship for 90 days from original purchase date if properly installed, and subject to normal use. Improper installation procedures, alterations, misuse and abuse of this product will void all stated warranty provisions. Products returned and deemed to be covered by warranty will either be replaced with said merchandise or issued credit for same.

TAG The Accessory Group Inc. 1025 Segovia circle Placentia Ca. 92870 714-630-6875