

RUSTY'S XJ CHEROKEE FENDER FLARES

PART #: XJFLR APPLICATION: '84-'01 Cherokee 2-door/4-door



Rusty's high quality, cut out flares are made from a tough durable urethane plastic. They are flexible but rigid enough to withstand the elements. These flares will open the fenderwell of your Cherokee from 2.5 to 4 inches, and an additional 1.25-inch of coverage for those larger tires and extra body protection. They come in a glossy black finish and can be painted. With over 2 years to develop, these flares are not a "make fit" or "something close". Rusty's flares are shaped just as the factory flares following the vehicle trim lines, but with the larger opening and more coverage giving your vehicle a great look.

TO INSTALL THE FLARES, YOU WILL NEED A NIBBLER, SAWS ALL, DRILL MOTOR WITH 1/8TH DRILL BIT, RIVET GUN, SMALL TOOL SET AND A MARKER.

- 1) Once you remove the factory flares, hold the Rusty's Cut Out's up to the body in the desired location, use the marker and mark the outline of the flare. DO NOT cut at this mark, cut 1/2 to 1 inch below the mark, this edge gives you the metal to rivet the flare to the fender.
- 2) Once the metal is removed, hold the flare into position and drill the 1/8th hole for the first rivet.
- 3) We recommend waxing the fender before installation. Install the rivets every 4 to 5 inches.
- 4) On some early models it will be necessary to trim the front fender flush with the bottom of the blinker.
- 5) Installation is not hard, just take your time and check everything before you cut. Once you get your Rusty's Cut Out Flares installed, your Cherokee will have the extra clearance and coverage for those larger tires, protection for the body and a great aggressive look.

WARNING

IT IS THE OWNERS' RESPONSIBILITY TO INSPECT ALL RUSTY'S PRODUCTS FOR PROPER TORQUE SPECS TO PREVENT LOOSENING OF COMPONENTS. BRAKING AND HANDLING CAPABILITIES ARE DECREASED WHEN LARGER TIRES AND WHEELS ARE USED. SEAT BELTS AND SHOULDER HARNESSES SHOULD BE WORN AT ALL TIMES. RE-CHECK ALL BOLTS AND NUTS AFTER THE FIRST 300 MILES AND AFTER ANY OFF-ROAD USAGE DURING THE FIRST 300 MILES. ALTHOUGH ALL OF OUR PRODUCTS ARE MADE FROM THE HIGHEST QUALITY MATERIALS POSSIBLE, THEY ARE NOT A SUBSTITUTE FOR SAFE AND CAREFUL DRIVING. IN OTHER WORDS, HAVE GOOD SAFE ON-ROAD / OFF-ROAD SENSE. KNOW THE TERRAIN, THE SPEED LIMITATIONS, AND ANY OBSTACLES THAT MAY LIE AHEAD. PLEASE REMEMBER TO PRESERVE OUR RIGHT TO ENJOY PUBLIC LAND THROUGH THE PROPER USE OF OFF-ROAD VEHICLES. THANK YOU FOR CHOOSING RUSTY'S OFF ROAD PRODUCTS.