

INSTALLATION INSTRUCTIONS

PART NO. 30459 STAINLESS STEEL WINDSHIELD WIPER MOTOR COVER

- A. Fasten Back Up Plate To Windshield Frame Using
5/32" & 1/8" Pop Rivets
- B. Mount and Fasten Wiper Motor Cover Using
1/4"-20 X 1/2" Long Hex Bolts
- C. Fasten Wiper Motor Cover Using #10-24 X 3/8" Long Bolts
(3-Required)
- C* Some Windshield Frames Have a Smaller Tapped Hole, Use
4 X .75 X 10MM Phillips Head Bolt In Place of the # 10 Hex Bolt

