

Warrior, Inc. 11100 SW Industrial Way Tualatin, OR 97062 Phone: (888) 220-6861 Fax: (503) 692-0364

<u>customerservice@warriorproducts.com</u> <u>www.warriorproducts.com</u>

JEEP YJ ROCK CRAWLER REAR BUMPER WITH RECEIVER

P/N: 575 / 576 / 577 / 580 INSTALLATION INSTRUCTIONS

- 1. Remove your existing bumper, or bumperettes, from your vehicle.
- 2. Install new bumper using the 7/16" lock nuts and washers provided. Washers should be placed between the nut and the frame. On some models the inside bolt holes are not drilled. You will need to align the bumper and drill holes 15/32" or ½". The gas tank may or may not need to be lower to install the inside nuts on to the bolts. It is difficult but can be done with out lowering the tank.
- 3. After initial test drive, check all bolts for tightness. You should check all bolts for tightness each time before using the receiver hitch for towing.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



